

Prestige [®]Adapter Pad

For use with AllStar° and Sizzix° Bigz™dies







Figure A

Figure B

Figure C

Placement

- 1. Place the material to be die-cut on top of the Cutting Pad (Figure A).
- 2. Place an AllStar ° or Bigz [™] die, blade side down, on top of the material (Figure B).
- 3. Place the Prestige[°] Adapter Pad on top of the die (Figure C).



Figure A

Figure B

Figure C

How to use with AllStar[°] Long and Bigz[™] L & XL dies

- 1. Align the back of die with the back of pressure plate and push down on the handle (Figure A).
- 2. Slide the Cutting Pad into the machine, so that the pressure plate is above the center of the die, and push down on the handle (Figure B).
- 3. Align the front of the die with the front of the pressure plate and push down on the handle (Figure C).

30265 Prestige * Adapter Pad