



It's a Cutting Pad... And it's an Adapter Pad!

Use your Bigz™ and AllStar™ Dies in your Prestige™ Machine.

Ellison® AllStar™ AllStar™ Machine Cutting Pad / Prestige™ Machines Adapter Pad

AllStar™ Cutting Pad



★ After prolonged use, the Cutting Pad tends to wear out and you may experience inconsistent cutting. Periodically flipping over the Cutting Pad will reduce wear.




★ Store the Cutting Pad in the front drawer.

★ Depending on use, replace the Cutting Pad after six months.

Prestige™ Adapter Pad



★ The Prestige™ Adapter Pad allows both Ellison® AllStar™ and Sizzix® Bigz™ Dies to be used with the Prestige Pro, Prestige Select and XL LetterMachine.



★ Place Prestige™ Adapter Pad on top of the Prestige Cutting or Crease Pad. Place paper on top of Adapter Pad. Place die, blade side down, on top of material to be cut.

E-Complete LLC ★ 1482 Linda Way Sparks NV 89431

Toll-Free: 877-4 DIE CUT (877-434-3288) ★ Fax: 775-358-0736 or 844-358-0736

Email us: Info@CompleteK-12.com ★ www.CompleteK-12.com