



**REQUIREMENTS:**

- Machine with 10" or wider opening

## Card, Pop-Up Multiple #1



**Figure A**



**Figure B**

1. Die-cut XL Pop-Up Multiple #1 Card from cardstock or other paper.
  2. Fold on all perforated or crease lines to make the pop-up tabs pop forward (Figure A).
  3. Fold Card in half to reinforce the folds. Tiny or small Ellison die-cuts or stickers can be attached to each pop-up tab.
  4. Cut a backing paper slightly larger than the Pop-Up Card or die-cut XL Card Cover A6 and attach to the back of the Pop-Up Card, leaving tab portions open (Figure B).
- Fits in A6 envelope. See Catalog or Ellison.com for complete listing.

**14347 Card, Pop-Up Multiple #1 (XL)**  
**12720 Card Cover A6 (XL), 17788 Card Cover A7 (XL)**

- Die available with perforation or crease rule. • Crease rule dies require Premium Cutting Pad.