




Original Ellison® LetterMachine® Cutting Pad



Replacing the Cutting Pad

1. When both sides of Cutting Pad no longer cut at least four sheets of construction paper with one pull of the handle, or scissors are required to complete a cut, the Cutting Pad needs to be replaced.
 2. If Cutting Pad is secured with flat-head screws, remove screws using a 1/8" hex wrench and set aside. If secured with Quick Change Pins, start with Step 3.
 3. Remove the Cutting Pad (Figure A) from the machine and discard.
 4. Remove and save any Mylar Shims under the Cutting Pad, leaving only the "I" Shim (Figure B) in place. Keep the "I" Shim in the machine AT ALL TIMES to properly distribute cutting pressure.
 5. Insert new Cutting Pad into the machine on top of the "I" Shim.
 6. Check the Cutting Pad height using the following procedures:
 - a. Using NO paper, place a Large Die with a symmetrical design (letter "O," "S" or Flower #1A) rubber side down into the machine on top of the Cutting Pad. Then pull the handle down once.
 - b. Slide the die and the Cutting Pad out of the machine to check the impression made by the die on the Cutting Pad. There should be a LIGHT impression of the entire die design on the Cutting Pad.
 - c. If no impression or an incomplete impression is made, add one Mylar Shim at a time, checking the die impression between the addition of each shim (maximum of four). Always leave the "I" Shim in the machine.
 - d. When a complete impression appears, try cutting four pieces of construction paper. If all pieces cut completely through, the Cutting Pad height is correct.
 7. Once Cutting Pad height is set, reinstall the flat-head screws. To prevent possible damage to the die rule and rubber, always make sure the screws sit slightly below the height of the Cutting Pad. Omit this step if using Quick Change Pins.
- Turn Cutting Pad over routinely (weekly for high usage) for even wear on both sides.

15456 - Original Standard Cutting Pad

Corporate Headquarters
25862 Commercentre Drive • Lake Forest, CA 92630-8804 USA
Within USA 800.253.2238 • Outside USA 949.598.8822
ellisoneducation.com

Ellison Europe Ltd.
Unit 3 • Whitegate Industrial Estate • Wrexham LL13 8UG, United Kingdom
Within UK 0871 222 2277 • Outside UK +44 (0) 845 345 2277
ellison europe.com